


Patch installation of Dr.ABE_Blank software v1.03.04

The patch for Dr.ABE_Blank version 1.03.04 can be located on Disc 2 or downloaded from the Amada support web site (<http://www.amadasupport.com>).
Please install the full version (1.03.03) before installing the patch.

*** Please back up your settings before performing the patch installation.
The backup file may be restored after the installation.**
(Please refer to the next section about the procedure of Backup/Restore.)

Do not run this installation from the Internet Site, please save it down to your Desktop before proceeding.

- At the completion of v1.03.04 patch installation (or restoring a backup), the following window may appear:



- Specify the Machine Series that corresponds to your particular machine(s).

Backup / Restore Setting

This section covers the procedure for Backup/Restore of machine/material parameters and various settings.

Backup


The backup file is a compressed file (.zip).

Please create a folder (C:\Dr.ABE Backup\) where the backup file will be saved.


Step 1 Click [System Setting].




Step 2 Click [System] tab, and click [Backup & Restore].



Step 3 Click [\[Browse\]](#).





Step 4 Select the folder, which was created beforehand, as the destination where the backup file will be saved, at [\[Look in:\]](#). Enter a name for saving the backup file in [\[File name:\]](#), and Click [\[Open\]](#) to finish.




Step5

Select all the checkboxes to the left panel of the screen, or use the Select All tab and click [\[Backup\]](#). The backup processing will be executed.




Step 6 The backup is completed. Click [\[Close\]](#).

Step 7 The backed up items will be displayed in the right hand panel of the screen. Click [X] to close the screen.



Step 8 Click [OK].



The complete parameters of Dr.ABE_Blank have now been backed up.


Restore Setting

Please follow this procedure for restoring your backup file. The existing production plan, various settings, machine/material parameters will be rewritten, so please be careful.


Step 1 Click [System Setting].




Step 2 Click [System] tab, and click [Backup & Restore].




Step 3 Click [Browse].



Step 4 At [Look in:], select the folder where backup file was saved. As for [File name:], select the backup file that will be restored from the list. Click [Open] to complete the process.



Step 5 Select all the checkboxes in the right panel of the screen, and click [Restore]. The Restore process will then be initiated.



Step 6 The restore is completed. Click [\[Close\]](#).

